



Connections and Settings for Using iPod/iPhone on the Unit

1 Check the connected cable.

- To listen to the music: USB 2.0 cable (accessory of the iPod/iPhone)



- To watch the video and listen to the music: USB Audio and Video cable JVC KS-U30 (separately purchased)



Caution

Videos cannot be played if connected with any cable other than JVC KS-U30.

2 Set <Input> on the unit.

The item to set on the unit varies depending on the connected cable.

1. Turn off the AV source.



2. Display the <Settings> screen.



3. Display the <Input> screen.



4. When connected with a USB 2.0 cable:

Set <Audio Input> to <AV-IN>.

For KW-AVX848/KW-AVX840/KW-ADV794/
 KW-AVX748/KW-AVX740



For KW-AVX640




You can listen to the music.


When connected with JVC KS-U30:

Set <Audio Input> and <Video Input> to <iPod>.

For KW-AVX848/KW-AVX840/KW-ADV794/
 KW-AVX748/KW-AVX740



For KW-AVX640




You can watch the video and listen to the music.

Using iPhone Navigation App (MotionX-GPS)

1 Confirm that the unit is connected with JVC KS-U30 (separately purchased).

MotionX-GPS cannot be used if connected with any cable other than JVC KS-U30.




2 Change the settings for using MotionX-GPS.

1. Turn off the AV source.




2. Set <Input> on the unit.



Set <Audio Input> and <Video Input> to <iPod>.

For KW-AVX848/KW-AVX840/KW-ADV794/
 KW-AVX748/KW-AVX740



For KW-AVX640




3. Display the "iPod" source control screen.



4. Display the <Mode> screen.



5. Set <iPod Control> to <External>.



3 Start MotionX-GPS from your iPhone.

4 Select "iPod" as the source.

The map displayed on the connected iPhone appears on the unit's display.

Caution

MotionX-GPS cannot be operated on the unit. Use iPhone to operate it.

• iPod and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries.